

# Spray On

## Product information

### Product description

Spray On is a liquid, aldehyde- and QAV-free, ready-to-use and alcohol based surface disinfectant.

### Area of application

It is suitable for disinfecting alcohol-resistant surfaces in the food sector, public facilities, and industry.



### Spectrum of activity

- bactericidal (incl. MRSA), yeasticidal
- active against enveloped viruses (incl. HBV, HIV, HCV, vaccinia-, influenza- and corona-viruses)

### Instructions for use

The ready-to-use product is preferably to be used in the wiping method using a disposable wipe. Spray disinfection should preferably be limited to areas that are not reachable by wiping disinfection. When using the spraying method, it should be combined with wiping for effective disinfection. It is important to keep the surface to be disinfected moist throughout the entire contact time to achieve effectiveness.



The biocide product Spray On (active ingredients Propan-1-ol and Propan-2-ol) has been approved for product type 2 (disinfectants and algacides not intended for direct application to humans and animals) and product Type 4 (food and feed area) with approval numbers EU-0027669-0000 and CH-0031683-0000. The union authorization is valid until July 31, 2032.

### Product range and specification

item number	container size	container type	packaging unit	PCN (each)	EAN/GTIN (each)	EAN/GTIN (packaging unit)
601211	1 L	club bottle	12 × 1 L	18312349	4260181251639	4260181251646
601210	5 L	canister	2 × 5 L	18312332	4260181253855	4260181251301

# Spray On

Product information

## Union authorization number

EU-0027669-0000

## Swiss authorization number

CH-0031683-0000

Use disinfectant safely. Always read the label and product information before use.

## Composition

### The active ingredients contained in 100 g:

45 g 2-Propanol

15 g 1-Propanol

## Storage and shelf life

### Shelf life:

24 months

### Shelf life after opening:

12 months

Close the container carefully after each use.

Store the product in a well-ventilated place in a sealed condition and protect it from unauthorized access.

## Exposure times

Spray On spectrum of activity	condition (dirty/clean)	exposure time	norm
bactericidal	with mechanical action dirty	1 minute	EN 13727 EN 16615*
yeasticidal	with mechanical action dirty	1 minute	EN 13624 EN 16615*
active against enveloped viruses (Modified Vaccinia Ankara)	dirty	1 minute	EN 14476

\* tested on reference wipe

## Informationen about this product



For further information,  
please visit our website  
[www.drdeppe.de](http://www.drdeppe.de)

For specific inquiries,  
please contact  
[info@drdeppe.de](mailto:info@drdeppe.de)



Laboratorium Dr. Deppe GmbH  
Hooghe Weg 35 · 47906 Kempen

T +49 (0) 2152 5565-0 W [www.drdeppe.de](http://www.drdeppe.de)